

Holznotenpult 11721/25/26/27

Wooden Stand 11721/25/26/27

Aufstellanleitung

Zum Befestigen der Füße Standsäule **2** umkehren und Spannschrauben **8** (3 Stück) bis zum Anschlag in Standsäule eindrehen (Abb. A). Füße **1** (3 Stück) aufstecken (Abb. B). Exzenterhülsen **7** (3 Stück) so einsetzen, dass der Pfeil zur Standsäule zeigt. Durch Verdrehen der Exzenterhülsen - *hierzu beigefügten Innensechskantschlüssel verwenden* - Fussteile an Standsäule spannen (Abb. C).

Auszug **3** in Standsäule einschieben und mit Holzschraube **9** in gewünschter Höhe festklemmen.

Gelenk **5** mit Kreuzschlitzschrauben **10** (2 Stück) an der Notenauflage **11** befestigen. Gummischeiben **4** (2 Stück) in Aussparungen am Auszug einlegen, Gelenk **5** darüber schieben und Notenauflage **11** mit Verschraubung **6** (2 Stück) in gewünschtem Neigungswinkel einstellen.

Assembly Instructions

TO ASSEMBLE FEET TO STAND, PLEASE TURN BASE COLUMN **2** DOWN AND SCREW THREADED LOCKING BOLTS **8** (3 PCS.) VERY TIGHT TO LIMIT STOP (PICTURE A). ATTACH FEET **1** (3 PCS./PICTURE B). INSERT LOCKING SCREWS **7** (3 PCS.) WITH ARROW POINTS TOWARDS COLUMN. USE ATTACHED ALLEN KEY TO FASTEN FEET TO COLUMN (PICTURE C).

INSERT EXTENSION COLUMN **3** INTO BASE COLUMN AND FASTEN WITH THE LOCKING NUT **9** AT THE DESIRED HEIGHT.

ASSEMBLE WOODEN CONNECTING JOINT **5** TO DESK **11** WITH COUNTERSINK SCREWS **10** (2 PCS.).

PLACE RUBBER WASHER **4** (2 PCS.) IN PROVIDED SPACE OF EXTENSION COLUMN **3** AND SLIDE CONNECTING JOINT OVER. FASTEN DESK **11** WITH THE LOCKING NUT **6** (2 PCS.) AT DESIRED ANGLE.

