

Baritonständer 14941

Aufstellanleitung

Füße **1** bis zum Anschlag nach außen klappen. Bügel **3** nach oben klappen und mittels Rändelmutter/Schloßschraube **2** am Unterteil festklemmen.

Zur Einstellung der gewünschten Breite

Schrauben **4** lösen und Bügel entsprechend auseinander- oder zusammenschieben, anschließend mit Schrauben **4** wieder fixieren.

Auflagenabstand min/max: 205/310 mm.

Zur Einstellung der gewünschten Höhe



Die Größe oder Bauart des Instruments, z.B. das Vorhandensein von Quartventilen, kann eine Anpassung der Höhe der seitlichen Bügel erfordern. Dazu: Abdeckkappen **5** entfernen. Sechskantmutter **7** mittels Ringschlüssel **6** lösen, obere Bügelschiene **3a** jeweils positionieren und Sechskantmutter **7** wieder festziehen. Abdeckkappen **5** aufdrücken.

Zur extremen Höhenverstellung

Abdeckkappen **5** entfernen und komplette Schraubverbindung lösen. Bügelschiene **3a** jeweils durch Einstecken der Schloßschrauben **9** in den entsprechenden Vierkantlöchern positionieren und mittels Sechskantmutter **7** und U-Scheiben **8** wieder fixieren. Abdeckkappen **5** aufdrücken.

Höhe min/max: 300/405 mm.

Weitergabe sowie Vervielfältigung dieses Dokuments, Verwertung und Mitteilung seines Inhalts sind verboten, soweit nicht ausdrücklich gestattet. Zuwiderhandlungen verpflichten zu Schadenersatz.



Made in Germany

Baritone Stands 14941

Set-up

Swing out the feet **1** as shown in the picture. Raise fold-up supports **3** and fasten them tight with the knurled nut/locking screw **2** at the lower ends.

Setting the width

Loosen screws **4** and slide the stands outwards or inwards to the desired width, then retighten the screws **4**.

Instrument widths min./max.: 205/310 mm.

Setting the height



The size or design of the instrument, e.g. the presence of quarter valves, may require the height of the side brackets to be adjusted. For this purpose:

Remove caps **5**. Loosen hexagonal nuts **7** using ring wrench **6**, reposition each of the upper rails **3a** and retighten the hexagonal nuts **7**. Replace caps **5**.

For extreme height adjustment

Remove caps **5** and completely detach the connecting screws. Position each of the rails **3a** by inserting the screws **9** into the appropriate square holes, replace washers **8** and refasten with the hexagonal nuts **7**. Replace caps **5**. Height min./max.: 300/405 mm.

Distribution and reproduction of this document, utilization and communication of its contents are prohibited unless expressly permitted. Contraventions will result in compensation.



Made in Germany