

18816 iPad-Halter

- passend zum 18810 »Omega« sowie zum 18950/53 Keyboard-Klapptisch
- Stabil, flexibel und praktisch:
das iPad wird einfach eingeclipst
- mit einem Handgriff steht das iPad hochkant oder quer
- einstellbar in Höhe und Neigung

Vielen Dank, dass Sie sich für dieses Produkt entschieden haben. Diese Anleitung informiert Sie über alle wichtigen Schritte bei Aufbau und Handhabung.

Wir empfehlen, sie auch für den späteren Gebrauch aufzubewahren.



SICHERHEITSHINWEISE

- Bitte beachten Sie die Angaben dieser Aufstellanleitung
- Ebenfalls Sicherheitsanweisungen und Aufbauanleitung der Keyboardständer und evtl. beteiligter Adapter beachten:
 - 18810 »Omega« zusammen mit 18814 Adapter
 - 18950/53 Klapptische direkt oder mit 18954 Adapter
- Auf feste Schraubverbindungen der beteiligten Artikel achten
- Vor dem Transport der Installation das iPad entnehmen
- Passend für **iPad 2. oder 3. Gen.**, nicht geeignet für iPad 1. Gen.
- iPad sorgfältig einclippen und auf Festzitz prüfen

AUFSTELLANLEITUNG

ZUSAMMENBAU der Baugruppen:

- 1 Querträger an Standrohr schrauben
- 2 Rändelschraube bis zum Anschlag festdrehen
- 3 iPad-Halter auf Standrohr schrauben
- 4 Rändelscheibe mit der Halterung verspannen



BAUGRUPPEN des iPad-Halters:

- A. Standrohr mit Gewinde
- B. iPad Aufnahmeplatte
- C. Querträger kpl.

MONTAGE

der iPad-Halterung ans Keyboardstativ:


5 18810 »Omega«:

- 18814 Adapter montieren;
- Querträger bis zum Anschlag in Adapter schieben
- Position durch Anziehen der Rändelschraube sichern

6 18950/18953 Keyboard-Klapptisch

Zwei Befestigungsmethoden: a. direkt, b. mittels Adapter

- Querträger C bis zum Anschlag ins Stativrohr schieben
- Zunächst Adapter 18954 montieren **6.b.1** und danach Querträger bis zum Anschlag ins Adapterrohr schieben **6.d.2**
- Stellung durch Anziehen der Rändelschraube sichern



18816 iPad-Halter

INSTALLATION

- der iPad-Aufnahmeplatte
7 Flügelmutter festziehen
8 iPad an der Unterkante einlegen und
9 oben einclippen

BENUTZERHINWEISE

Der vorliegende iPad-Halter kann in Höhe, Neigung und Format verstellt werden. Und auch die Keyboardständer selbst sind vielfach einstellbar.

WIR RATEN:

- Beim Einstellen der Höhe bzw. beim Transportieren des Statives das iPad zuvor aus der Aufnahmeplatte zu entnehmen, da es leicht zu "unkontrollierten" Bewegungen kommen kann.
- Beim Verstellen des Formats oder der Neigung würden wir das iPad in der Platte belassen - unter Wahrung der üblichen Umsicht.

10 HÖHE

Standrohr festhalten, Klemmschraube vollständig aus dem Querträger herausschrauben, gewünschte Bohrung des Standrohres wählen und mittels Klemmschraube wieder am Querträger befestigen.

11 NEIGUNG

Seitliche Flügelmutter 7 lösen und den Winkel der Aufnahmeplatte einstellen. Mutter wieder anziehen.

12 FORMAT

Platte kann um 90° verdreht werden, so dass das iPad hochkant oder quer präsentiert werden kann. Anschläge begrenzen die Verdrehung.

TIPP: Einschaltknopf unten **12.a** oder rechts **12.b** platzieren, da so die Kabel-Zugkräfte gegen den Anschlag wirken.

INSTANDHALTEN, REINIGEN

- bei Wartungsarbeiten zuvor iPad entnehmen und auf evtl. Gefährdungen achten
- zur Reinigung ein leicht feuchtes Tuch und sanftes Reinigungsmittel benutzen

FEHLERSUCHE (F) und BESEITIGUNG (B)

F: Halterung wackelt

- Standrohr ist nicht fest genug mit dem Querträger verschraubt
- Querträger ist nicht fest genug mit dem Adapter bzw. dem Keyboardstativ verbunden
- Adapter ist nicht fest genug mit dem Keyboardstativ verschraubt


F: Platte wackelt

- Flügelmutter nachziehen


F: SITZ des iPad in der Halterung

- Aufnahmeplatte sanft aber bestimmt zurechtbiegen
- ACHTUNG!** Nicht für iPad 1. Gen. geeignet. Bitte iPad prüfen.


INSTALLATION




HÖHE




NEIGUNG




FORMAT



TIPP




12.a




12.b

SITZ


falls das iPad zu locker sitzt



iPad entnehmen und Halterung sanft aber bestimmt nach innen biegen



iPad wieder einclippen, testen und evtl. erneut biegen



TECHNISCHE DATEN / SPEZIFIKATION

Material	Griffe, Platte: PA, schwarz Standrohr, Querträger: Stahl, schwarz
Traglast	iPad 2. Generation (630 g), iPad 3. Generation (670 g)
Maße	Aufnahmeplatte: 252,1 x 104,8 x 195,4 mm
Karton	385 x 265 x 145 mm
Gewicht	netto: 1,2 kg, brutto: 1,6 kg

18816 iPad Holder

- Suitable for 18810 »Omega« and 18950/53 table-style keyboard stand
- Stabile, flexible and practical: iPad simple to clip in
- Vertical or horizontal viewing with one manipulation
- Height and tilt adjustable

Thank you for choosing this product. This instruction manual informs you about the important steps to set up and handle the product. We recommend to keep the manual in a separate place for a possible later use.



SAFETY NOTES

- Please observe the information in these assembly instructions
- Similarly, observe the safety notes and construction instructions for the keyboard stands and adapter – if used:
 - 18810 »Omega« together with 18814 Adapter
 - 18950/53 table-style keyboard stand directly or using 18954 Adapter
- Ensure that the screw connections are tight for all components
- Remove the iPad before transporting the installation
- suitable for **iPad 2. or 3. Gen.**, not suitable for iPad 1. Gen.
- clip the iPad carefully into the cradle and check it - is held correctly

ASSEMBLY INSTRUCTIONS

ASSEMBLY of the components:

- 1 Screw the cross rod onto the stand rod
- 2 Screw in the knurled screw up to the stop
- 3 Attach the iPad Holder to the stand rod
- 4 Tense the knurled screw with the holder



COMPONENTS of the iPad Holder:
A. Stand rod with thread
B. iPad2/3 cradle
C. Cross rod components

MOUNTING

the iPad Holder on the keyboard stand:


5 18810 »Omega«:

- Attach 18814 adapter;
- Push in cross rod in the adapter up to the stop position
- Fix by tightening the knurled screw

6 18950/18953 table-style keyboard stand

Two attachment methods: a. directly, b. with an adapter

- Push in cross rod **C** in the stand rod up to stop
- First Attach the 18954 adapter **6.b.1** and then push in cross rod in the adapter rod up to stop **6.b.2**
- Fix by tightening the knurled screw



18816 iPad Holder

INSTALLATION

of the iPad cradle

7 tighten wing nuts

8 slot in the iPad at the lower edge and

9 clip in at the top

NOTES FOR USE

The tilt and viewing format of this iPad Holder can be adjusted.

And the keyboards are easy to adjust.

WE RECOMMEND:

- When adjusting the height, e.g. for transporting the stand, removing the iPad from the cradle, as jolting may be unavoidable.
- When changing the viewing format or tilt, we suggest leaving the iPad in the cradle – but nonetheless moving it with care.

10 HEIGHT

Hold the stand rod firmly, remove the clamping screw from the cross bar completely, select a bore hole on the stand rod and re-attach to the cross rod using the clamping screw.

11 TILT

Loosen side wing nut 7 and set the tilt of the cradle. Re-tighten the nut.

12 FORMAT

The cradle can be turned 90° so that the iPad is presented either vertically or horizontally.

Stop mechanisms prevent slipping.

TIP: Place the on button under 12.a or right 12.b so the pull of the cable works against the stop mechanism.

MAINTENANCE, CLEANING

- Remove the iPad before starting maintenance and be aware of potential hazards
- For cleaning purposes utilise a slightly damp cloth with a non-abrasive cleaning solvent

FAULT FINDING (FF) & SOLUTION (S)

FF: The holder wobbles

S: Cross bar is not attached to the stand section firmly

S: Cross bar and adapter/keyboard stand are not connected firmly

S: Adapter is not screwed tightly to the keyboard stand

FF: Cradle wobbles


S: Tighten wing nuts

FF: SEAT of the iPad in the holder


S: Gently bend the adapter plate into position 13

S: NOTE! Not suitable for iPad 1. Generation


INSTALLATION




HEIGHT




TILT




FORMAT



TIPP



12.a




12.b

SEAT

if the iPad is too loose

remove iPad and bend the holder gently but firmly inside

attach the iPad again, test it and bend it again if required



TECHNICAL DATA / SPECIFICATIONS

Material	grips, cradle: PA, black stand rod, cross rod: steel
max. load	iPad 2. Generation (630 g), iPad 3. Generation (670 g)
Size	cradle: 252.1 x 104.8 x 195.4 mm
Card	385 x 265 x 145 mm
Weight	net: 1.2 kg, gross: 1.6 kg